## **TABLE OF CONTENTS**

Index

For vehicles with a navigation system, refer to the "Navigation System Owner's Manual" for information regarding the equipment listed below.

•	Air conditioning Windshield wiper de-icer Rear view monitor system	• R	ear window and outside rear view irror defogging limate control
1	Before driving	1-4.	Adjustable components (seats, mirrors, steering wheel)
			Front seats
1-1.	Hybrid system		Rear seats
	Hybrid system features24		Driving position memory 80
	Hybrid system precautions 29		Head restraints83
	Energy monitor/		Seat belts 86
	consumption screen35		Steering wheel94
	Hybrid vehicle driving tips		Inside rear view mirror
			Outside rear view mirrors 97
1-2	Key information		
	Keys 43	1-5.	Opening and closing
			the windows and moon roof
1-3	Opening, closing and locking		Power windows 100
	the doors		Moon roof 103
	Smart access system with push-button start	1-6.	Refueling
	Wireless remote control 61		Opening the fuel tank cap 107
	Side doors 66		Opening the raci tank cap 107
	Back door 70		

1-7.	Theft deterrent system Immobilizer system	2	When driving	
	Alarm	2-1.	Driving procedures  Driving the vehicle	1
1-8.	Safety information  Correct driving posture		Power (ignition) switch       169         EV drive mode       174         Hybrid transmission       177         Turn signal lever       185         Parking brake       186	2
	classification system	2-2.	Horn 187	3
			Gauges and meters	4
	2-3.	Operating the lights and windshield wipers	5	
			Headlight switch	6
			Rear window wiper and washer	7

## TABLE OF CONTENTS

ı			ı		
H	ኅ	C	le	2	x

2-4.	Using other driving systems		1
	Cruise control 216	3	Interior features
	Dynamic radar cruise control	3-1.	Using the air conditioning system and defogger
	Rear view monitor system		Automatic air conditioning system
	Hill-start assist control		Rear window defogger switch
2-5.	Driving information		
	Cargo and luggage	3-2	. Using the audio system
	Vehicle load limits		Audio system types 291
	Winter driving tips 270		Using the radio295
	Trailer towing		Using the CD player307
	Dinghy towing 275		Playing MP3 and WMA discs
			Operating an iPod329
			Operating a USB memory 341
			Optimal use of the audio system
			Using the AUX port
			Using the steering wheel audio switches

3-3.	Using the Bluetooth® audio system Bluetooth® audio system 360	3-5.	Using the interior lights Interior lights list	
	Using the Bluetooth <sup>®</sup> audio system		main switch	1
	portable player	3-6.	Using the storage features	2
	Bluetooth <sup>®</sup> audio system setup		• Glove box	
3-4.	Using the hands-free phone system (for cellular phones)		<ul> <li>Cup holders</li></ul>	3
	Hands-free system for cellular phones	3-7.	Other interior features Sun visors	4
	Making a phone call		Clock	5
			Seat heaters	6
			Garage door opener	7

## 4 Maintenance and care

4-1.	Maintenance and care	
	Cleaning and protecting the vehicle exterior	474
	Cleaning and protecting the vehicle interior	. 479
4-2.	Maintenance	
	Maintenance requirements	482
	General maintenance	484
	Emission inspection and maintenance (I/M)	
	programs	488
4-3.	Do-it-yourself maintenance	
	Do-it-yourself service	400
	precautions	
	Hood	
	Positioning a floor jack	
	Engine compartment	
	12-volt battery	
	Tires	
	Tire inflation pressure	
	Wheels	534
	Air conditioning filter	537
	Electronic key battery	539
	Checking and replacing fuses	542
	Light bulbs	554

## 5 When trouble arises

5-1.	Essential information	
	Emergency flashers570	)
	If your vehicle needs to be towed	1
	If you think something is wrong 577	7
	Event data recorder578	3
5-2.	Steps to take in an emergency	
	If a warning light turns on or a warning buzzer sounds 580	)
	If a warning message is displayed	3
	If you have a flat tire 615	5
	If the hybrid system will not start	)
	If you lose your keys63	
	If the electronic key does not operate properly	
	If the 12-volt battery is discharged	
	If your vehicle overheats 640	
	If the vehicle becomes stuck	
	If your vehicle has to be stopped in an emergency 647	7

6	Vehicle specifications	Index	
6-1.	Specifications	Abbreviation list	722
	Maintenance data (fuel, oil level, etc.)	Alphabetical index	724
	Fuel information		
	Tire information 668	What to do if	736 <sub>2</sub>
6-2.	Customization		
	Customizable features 684		
6-3.	Initialization		3
	Items to initialize705		
7	For owners		4
	Reporting safety defects for U.S. owners 708		5
	Seat belt instructions for Canadian owners		
	(in French)709 SRS airbag instructions for Canadian owners		6
	(in French)711		
			7